

902 193 714

Emac Complementos S.L.

Avda. Madrid 6 apdo. Postal 46 9450 N.W. 12 St. 46930 Quart de Poblet Valencia - Spain Tel. (+34) 96 153 22 00 Fax. (+34) 96 153 22 61 e-mail: info@emac.es www.emac.es

EMAC AMERICA L.L.C.

MIAMI, FL 33172 2344 E. Walnut Ave. FULLERTON, CA 92831 Phone # (305) 406 15 93 Fax: (305) 406 1793 e-mail: sales@emac.es

FICHA TÉCNICA

SPECIFICATION SHEET

FICHE TECNIQUE


SPEZIFIERUNGSBETTUCH

Novotrap[®]

Material: Steel + magnet

R Patented product as desian.

Patent number: 127.402(3)





NOVOTRAP®

Magnetic support system to make access plates with pieces of the same tiles area, allowing an easy and discreet access to pipelines, mechanisms, motors etc., which remain completely hidden from the exterior.

It is very useful for bathtubs, hydro massage systems, and also to create small secret boxes.

TECHNICAL CHARACTERISTICS

- Set consisting of four magnets and four steel bases.
- Novotrap® supports even 5 Kg. of weight.
- Example of support capacity of Novotrap[®]: Ref. a marble of 2,85 g/cm³ density and 1,5 cm. of thickness. Novotrap® set might support a format with maximum dimensions: 25 cm. x 40

This is possible since 2,85 g/cm³ x (1,5 x 25×40) cm³ is < 5000 g.

PLACEMENT

- 1. To place Novotrap[®], the four magnets will be placed on the four vertexes of the hole to be covered.
- 2. Make sure that only the magnets are visible, while the fixing wings are caught behind the tile with the fixing material.
- 3. Then, fix the four metallic plates to the covering tile onto the four vertexes, so that when super-imposing them on the magnetized bases, they coincide with the magnets placed in the hole.

See pictures of placement in the next page.

FICHE TECNIQUE





TECHNICAL INFORMATION



If you have some doubt, wishes information about some characteristic, do not

hesitate to contact with EMAC®'s technical department: otecnica@emac.es

FICHA TÉCNICA